

# MUSTACHE TRIMMER

## Instructions


### TRIMMING AND EDGING YOUR BEARD

The following are suggested trimming steps and trimmer positions. You may find different procedures work better for you.

1. Comb your beard in the direction that it grows to help reveal stray hairs that may be longer than the others.
2. Attach guide to trim or taper your beard. Begin with the longer guide. Trim toward your chin in smooth, overlapping strokes, following the lay of your beard to avoid patchy results. If you trim against the way your beard naturally lays, the trimmer will cut the hair much shorter. Continue switching to shorter guides until desired length is achieved. You may want to use the closer guide near ear and down under chin, changing to a longer guide toward front of face and point of your chin.
3. To cut the outline of your beard, remove the trimming guide. Starting under your chin and working back toward your jawbone and ears, cut the outer perimeter of your beard underneath the jawbone. Continue the line all the way up to the ears and hairline.
4. Accentuate your beard line by using the trimmer in a downward motion. Start at the line you've created and, working from the chin back toward the ears, trim the area right under your beard line.
5. Define the upper part of your beard using the same technique.


### TRIMMING YOUR MUSTACHE

1. Comb your mustache.
2. To define the line of your mustache, begin with the trimmer blade.
3. For tapering the mustache, hold the trimmer with the blades pointing upward. Place the #2 (1/8") guide comb on trimmer. Starting in the middle of your mustache, taper with short upward strokes, working out toward the corners until a gentle shape is created on the bottom of your mustache.



### TRIMMING WITH ATTACHMENT COMBS

Your trimmer includes three trimming attachments; stubble, medium and long. The stubble guide has 1 bar, the medium-cut attachment has two bars and the long-cut attachment has three bars. These attachments are ideal for blending, tapering and defining beards, as well as for achieving a "close trim" stubble look around the face. To use the attachments, go with the hair direction. To achieve closer looks, go against the hair direction.



### USE YOUR WAHL TRIMMER ON HAIR, TOO

That's part of its job. You can use it to keep expensive hairstyles trimmed—shaping hairlines, defining parts and trimming around neck and ears. You can use it to style hair, too, if you wish.

To trim or style hair, first shampoo and dry hair thoroughly. Fluff out evenly.

Then, holding the Wahl trimmer with toothed edge pointed down, trim off a little at a time, carefully. It may be best to have someone else help you.

Eventually you should develop the skills to stay well groomed by a quick trim around neck, ears and sideburns.

### BODY SCAPING

Your trimmer makes for the perfect tool to groom areas below the neck. Using the same technique, as mentioned prior, you can groom wherever you feel a need.

For the cleaning and care instructions of your trimmer, please download the Care Instructions

### SERVICE AND REPAIR

If you have problems with your WAHL product, send it prepaid with a note explaining the problem to:  
Wahl Clipper Corporation  
Attn: Repair Department  
3001 Locust Street  
Sterling, IL 61081  
Telephone (815) 625-6525  
For products purchased outside the United States, contact your distributor.